

INSTALLATION INSTRUCTIONS

TOPAZ SLIMLINE DRAWER SYSTEM – H167

Australia

1800 008 591 ■ www.artia.com.au

VICTORIA:
235 Settlement Road,
Thomastown VIC 3074

NEW SOUTH WALES:
Unit 1/429 Victoria Street,
Wetherill Park NSW 2164

QUEENSLAND:
Building 2/660 MacArthur
Avenue, Pinkenba QLD 4008

SOUTH AUSTRALIA:
13 Rosberg Road,
Wingfield SA 5013

WESTERN AUSTRALIA:
Unit 1B/15 Hector Street,
Osborne Park WA 6017

New Zealand

0800 267 625 ■ www.artia.co.nz

AUCKLAND:
11 Bruce Roderick Drive,
East Tamaki, Auckland 2013

CHRISTCHURCH:
117 Wrights Road,
Addington, Christchurch 8024

Basic components 		Cutting dimensions for 16mm board <p>KB : Cabinet width LW : Internal cabinet width NL : Nominal length</p>	
Cabinet space requirements 	Mounting dimensions Front brackets 	Drilling dimensions Front panel 	Mounting dimensions Back panel
Slide mounting hole distances 		Carcase mounting dimensions 	
Drawer assembly			
<p>1</p>	<p>2</p>	<p>3</p>	
<p>4</p>	<p>5</p>	<p>6</p>	

KB = Cabinet width | LW = Internal cabinet width | NL = Nominal length

All dimensions in millimetres

Drawer installation <p>"Click"</p>		
Drawer front adjustment		
<p>Horizontal / left & right adjustment ±1.5mm</p>	<p>Vertical / up & down adjustment ±1.5mm</p>	<p>Front panel release</p>
Drawer removal		
<p>Cover cap removal</p>	<p>Drawer release mechanism</p>	
Drawer removal 		

Technical information only. Component parts for different drawer types or configurations to be ordered as required.



NZ: 0800 267 625 ■ www.artia.co.nz

AUS: 1800 008 591 ■ www.artia.com.au